



Promessa™ Series Towel Bar

Revised: 10/18/16

Installation Procedures For The Following Models:


**Model T102-011
Towel Bar (Contemporary)**



**Model T102-012
Towel Bar (Traditional)**



STEP 1 Understand Fastener




Warning: Each threaded stud is covered with a plastic thumb screw to prevent thin-set mortar from corrupting threads. Do not remove until after grouting.

- Prepackaged plastic thumb screws should not be removed until after grouting.
- Each fastener is equipped with a stabilizing bracket. The bracket ensures that each towel bar system will mount at the predetermined location. Remove stabilizer after thin-set has met minimum cure times specified by manufacturer.

Not using stabilizer will result in towel bar mounting failure

STEP 2 Determine Towel Bar Location


- Determine the wall surface where the PermaTile™ Fastener should be located.
- Apply thin-set mortar with no less than a 1/4" x 3/8" notch trowel.



Warning: Use only latex modified mortars that meet ANSI A118.4/A118.11 performance standard.


Note: System will not work on tile thicknesses less than 5/32" or greater than 1/2"

STEP 3 Install PermaTile™ Fastener



- Key thin-set mortar into the back side of tile to ensure proper contact and adhesion.
- Press the PermaTile™ Fastener into the combed thin-set mortar at the predetermined location.
- Adjust as necessary, setting stud directly on tile edge.

STEP 4 Mark & Notch Tiles




- Mark notch locations.
- Using an angle grinder, remove enough material allowing 1/16" of adjustment side to side and up and down.

Warning: Notches and holes should not exceed 3/8" in diameter to ensure towel bar trim has sufficient surface area during mounting.

Technical Fact:

Procedures for installing PermaTile™ Fastener in the body of the tile. Use only 10mm diamond drill bit (core). Use Stabilizer as drilling template.







Promessa™ Series Towel Bar

Installation Procedures For T102-011 & T102-012

STEP 5 Install Notched Tiles




- Key thin-set mortar into the back side of tile to ensure proper contact and adhesion.
- Press tile into wall and adjust as necessary.
- Remount stabilizer, make sure it fits freely.



Warning: Do not proceed with accessory installation until thin-set mortar has met minimum curing requirements specified by manufacturer.



Remount stabilizer

STEP 6 Understanding Screwdriver





- Towel rod was designed with (2) 1/4" holes which will allow a 3/16" screwdriver to be inserted.

STEP 8 Mount Rod & Left Side Sleeve



1. Insert towel rod into right side sleeve.
2. Insert 8-32 stainless steel screw into sleeve (screw must be in sleeve before mounting can occur)
3. Slip sleeve onto towel rod and insert both together over threaded stud.
4. Using a #2 phillips head screwdriver, attach screw and sleeve firmly to tile wall.

STEP 7 Mount Right Side Sleeve



- Remove plastic thumb screws & stabilizer after grouting.
- Starting on right side, simply slip sleeve over threaded stud, insert 8-32 stainless steel screw and attach.
- Using a #2 phillips head screwdriver, attach screw firmly to tile wall. (Sleeve attachment hole should be visible and facing left)

Warning: Each threaded stud is covered with a plastic thumb screw to prevent thin-set mortar from corrupting thread. Do not remove until grouting is complete.

Thank you for using our products!

TileWare Products
 PO Box 793, Hickory, NC 28603
 Technical Support: 828-322-9273
 Email: info@tilewareproducts.com
www.tilewareproducts.com

STEP 9 Attached Caps & Anti-Rotation



- Thread on caps.
- One cap is equipped with an anti-rotation screw. Slip cap & anti-rotation screw assembly into predrilled 1/4" hole located in towel rod, then thread onto sleeve.
- Installation complete.

Towel Bar Parts List

Model	Fastener Assembly quantity 1 per kit	Rod quantity 1 per kit	Sleeve quantity 2 per kit	Cap quantity 1 per kit	Cap & Anti-rotation Screw Assembly quantity 1 per kit	8-32 Screw quantity 2 per kit
T101-011 or T101-012 Towel Bar Kits	PT100-508	C220-007	C220-001	C220-005 or C220-012 Contemporary - Traditional	C100-005	C200-013